

QUICK-CONNECT FITTING



AQC150K 1-1/2 inch

FITS MOST SUMP & EFFLUENT PUMPS

AQC200K 2 inch

FITS MOST SEWAGE PUMPS

3 STEP INSTALLATION



1. Insert the Quick-Connect fitting into the pump discharge outlet and tighten.



2. Insert the PVC pipe into the fitting as far as possible.



3. Hand-tighten the fitting around the PVC pipe.



For assistance call: **1-844-242-2475** or visit www.K2pumps.com